

# ZEEKR 7X Australia

## Zeekr 7X Voice Commands

How to Activate:

- 1) Wake Word: Say "Hi Zeekr" or "Hey Zeekr" to wake the assistant.
- 2) Steering Wheel: Press the Voice Control button on the steering wheel to trigger the listener manually.

Permissions:

Ensure voice recognition is enabled in the Privacy Settings on the central display if it's not responding.

The assistant can handle both direct instructions and more granular requests.

It also knows which seat position the command has come from. 4 corner speakers in the roof pick this up. ie if the person in the rear right says "Hey Zeekr turn on my heated seat" only the rear right heated seat will turn on.

Some Common English Voice Commands:

Climate Control:

"Set the temperature to 22 degrees" "Turn on seat heating" "I'm cold".

Navigation:

"Navigate home" "Take me to [Destination]" "Find the nearest charging station" "Navigate to Storm Street".

Windows & Doors:

"Open the sunshade" "Close the tailgate" "Open rear left window by 50%".

Media:

"Play music" "Play radio" "Volume up/down" "Set voice navigation volume to 10".

Vehicle Information:

"What is my remaining range?" "Check tyre pressure".

Phone:

"Call Paul" "Call back".

Controls:

"Enable Seat Massage" "Open the window" "Turn on Bluetooth" "Mute".

The following commands do not require the use of "Hi Zeekr, Hey Zeekr, nor the Steering Wheel Voice Button":

"Answer Call" "Decline Call" "Play Music" "Pause Music" "Resume Music" "Next Music" "Previous Music".

With all voice commands if you follow the below structure you will have more success on giving voice commands:

- 1) Action: What you want to do (ie: Turn on, Increase, Set).
- 2) Target: What you want to affect (ie: Wi-Fi, Volume, Brightness).
- 3) Modifier/Value: Any additional information to specify the action (ie: to 20%, to level five, to maximum).

Examples: "Turn on Wi-Fi" "Increase the volume to 20%".

Voice control limitations:

The voice control system understands most natural speech patterns and can filter out some background noise.

However, some factors might limit the ability of the voice control system to recognize voice commands, including:

- Excessively unclear pronunciation.
- Excessively long or complex commands or questions.
- Loud noise levels inside the car.